

FREEGARDEN EARTH BACKYARD COMPOSTER



The FreeGarden Earth is a backyard composter that takes yard waste and fruit and vegetable kitchen scraps and turns them into rich finished compost.

FEATURES:

- One piece design – no seams or assembly required
- 33” high x 31” wide
- Made of 100% recycled material
- Rodent resistant
- Twist locking lid

USING YOUR COMPOSTER – 6 EASY STEPS

1. **Assemble** your Composter according to the instruction booklet provided and place in a flat, convenient location.
2. **Alternate layers of green (nitrogen rich) and brown (carbon rich) materials.** Chopping up larger material for faster decomposition.

GREEN MATERIAL (Nitrogen Rich)	BROWN MATERIAL (Carbon Rich)
Vegetables and fruits, fresh grass, coffee grounds/tea bags, green plant trimmings, weeds that have not gone to seed	Dry brown leaves and plants, dry brown grass clippings, corn stalks, straw, shredded newspapers
DO NOT put meats, bones, greasy foods, oils, grains, dog and cat waste, cooked foods or pesticide treated grass or weeds into your composter.	

3. **Bury food scraps** within your pile and cover with a layer of brown material (fall leaves work great so save them up for future use).
4. **Mix the contents** every few weeks. This adds air to the pile and gets decomposition going faster. You could use an old ski pole or dig with a pitch fork.
5. **Watch the moisture** content. The materials in the bins should feel like a wrung out sponge. Add water if it is very dry
6. **Harvest your compost.** Finished compost looks like dirt and is sweet smelling. You can use a screen to separate material that has not finished composting yet. Dig into gardens or use around plants and trees.

For more detailed information about the FreeGarden Earth visit the [Enviroworld Website](#)